



HOT WATER

Troubleshooting Guide

1

IS THERE ANY HOT WATER?
Cold only OR only warm/running out

2

Is your hot water system gas or electric?
Gas - A plumber is required.
Electric - Lume Electrical can help you.

3

Electric hot water system and an issue with water temperature?
Locate your switchboard, and check has your circuit breaker tripped?

4

If you can reset the circuit breaker, wait 2 hours for your tank to fill up. Then check, is it hot? If yes, hot water restored.

5

Still no hot water and/or your circuit breaker did not reset?
There is an electrical fault.
Contact Lume Electrical to attend.
[BOOK ONLINE NOW](#) or call 0497084854



0497 084 854

WWW.LUMEELECTRICAL.COM

